

If your camera's HW is IPC\_5128M, then you may update the firmware of IPC\_5128M.610\_19121001.D400.ov4689.4MP.REOLINK.pak


If your camera's HW is IPC\_5174MP8M, then you may update the firmware of IPC\_5174MP8M.610\_19121001.D400.ov4689.4MP.REOLINK.pak **or** IPC\_5174MP8M.610\_19121001.D400.ov4689.4MP.REOLINK.IPC\_5174MP8M



You may refer to the following two steps to check the firmware version for the cameras which are connected to the Reolink PoE NVR.

**Step 1.** Click the  icon to go to the **Menu** page of the NVR, then choose **IP channel** to

proceed.



**Step 2.** Select the channel you want to check firmware version for, then tap on **Detail** and you can see the **FW**

**Version.**

