

Reolink Firmware Upgrade Guide

Applies to: Reolink E1 outdoor

Firmware for hardware version IPC_523SD8

If your model is not listed above or the hardware version of your camera is not the exact number listed above, please do not upgrade this firmware. If you upgrade wrong firmware, it may brick your camera.

Attention for firmware upgrade:

- If you don't want to restore your camera settings to factory status, please uncheck the "Update Configuration Files" option during the upgrade.
- During the upgrading procedure, please do not power off the camera.
- Make sure your camera has the correct model and hardware version listed above, otherwise, please do not upgrade this firmware.


1. Check your current camera firmware version.

To ensure you upgrade the correct firmware, please check your camera model on the product sticker or System Information page via Reolink App or Reolink Client software.

On Reolink App, tap on the gear icon to go to the **Device Settings** page. Slide the screen to the top, then click on camera, and then you will find the **Device Info** of your camera.

reolink

< Settings



e1 outdoor

Model: E1 Outdoor

95270000WDWXVXT1

>

Network baichuan608 >

Display >

Alarm Settings

Motion Detection >

Camera Recording On >

Spotlight On >

Notification Settings

Push Notifications ☐

Email Alerts >

Siren Off >

< Device Info

Device name e1 outdoor >

Model E1 Outdoor

UID 95270000WDWXVXT1

Storage Not detected >

Network Info IP Address, etc. >

System Info

Upgrade Device >

Build No. build 21020326


Hardware Ver. IPC_523SD8

Config Ver. v3.0.0.0

Firmware Ver. v3.0.0.188_21020326

Detail IPC_523SD8S10E1W31100000001

On Reolink Client,click **Device Settings** button then click **Info** icon.



At the Information page, please ensure your camera model is correct, and the Hardware version is IPC_523SD8, so you can upgrade this firmware.


To read the camera's firmware version via Build No, for example build 21020326, the larger the numbers are the newer the firmware is.

2. Upgrade steps.

Take Reolink Client (Windows) for example:

Step 1: Launch Reolink Client and log in to your camera, then go to **Device Settings** -> **System** -> **Maintenance** page.

Step 2: Tap on **Browse** to select the correct upgrade file **xxx**, then click **Upgrade** to start upgrading firmware.



Note:

If you don't want to restore your camera settings to factory status, please uncheck the "Update Configuration Files" option.

During the upgrading procedure, please do not power off the camera.

For more upgrade guides on other software platforms, please read:

<https://support.reolink.com/hc/en-us/articles/360008743073-How-to-Upgrade-the-Firmware-for-Reolink-Products>